


COMPONENT TABLE			
COMP	VALUE	TOL ±%	CAT No.
R1,2	100	5	5662
R3,4	10	5	9823
MR1,2	ZENER DIODE		2569
MR3,4	CONTROL RECTIFIERS		11221
FS1	1A		4287
FS2	3A		615
Fuseholder			622
Filter	1 phase 2.5 Amp		PS 381
PU1,2	Power Supply ELV 100		11258
PU3	Power Supply ELV 500		11186

Figure 2 (ISSUE 2)







Figure 3 (ISSUE 2)



BOARD TYPE	BOARD POSITION	1 A	2 A	3 A	4 A	5 A	6 A	7 A	1 B	2 B	3 B	4 B	5 B	6 B	7 B
DP101	17	01	01	01	01	01	15		36	36	36	11	11	11	02
DP102	16	01	01	01	129	01	129	08	12	12	12	31	32	01	02
DP 103	15								12	35	12	35	12	35	35
DP 104	14, 6, 2	129	02	01	129	38	01	38	01	01	31	32	01	01	11
DP 105	13, 5	01	01			15			36	01	36	01	36	01	02
DP 106	12, 4	01	129	129		01			02	01		31	32		
DP107	11, 3								35	35	35	35			
DP108	18								12	01	01	01	01		

BOARD TYPE	BOARD POSITION	G AREA PAD LOCATION	VALUE	TOLERANCE ± %	CAT. NO.
DP102	16	1/7	0.01	5	7922
		9/15	0.01	5	7917
DP106	12, 8, 4	27/33	0.047		7044
		28/34	0.047		7920
DP103	15	3/4 7/8 9/10 11/12 19/20 21/22 23/24, 27/28, 29/30			
DP107	11, 7, 3	31/32	220	5	9024
DP104	14, 10, 6, 2	1/7 2/8 31/33	0.01	5	7917
		9/15	0.047	5	7044
		17/23	0.0068	5	7921
		25/27	680pF	5	11361
ALL BOARDS		C1, C2, C3.	10	20	9137




Figure 6 (ISSUE 2)